

X-Arcade is a serie of controllers from XGaming Corp.

It includes the following controllers :

	Name	Players buttons	Flipper buttons	Trackball	Spinners	Plunger	Comment
	X-Arcade Tankstick	Automatic	Automatic	Manual	N/A	N/A	Out of the box configuration with batocera 44. Trackball not yet configured automatically.
	X-Arcade Tankstick MAX	Automatic	Automatic	Manual	Manual	N/A	Out of the box configuration with batocera 44. Trackball and spinners not yet configured automatically.
	Arcade2TV-XR	Automatic	Automatic	Manual	Manual	N/A	Out of the box configuration with batocera 44. Trackball not yet configured automatically.
	Arcade2TV-XR MAX	Automatic	Automatic	Manual	Manual	Automatic	Product not yet available

Modes

Mode	
Keyboard	This is the mode making all work magically. Recommended. In batocera, it uses keyboardtopads.
DINPUT	No trackball and no player2. Working partially and discouraged mode.
XINPUT	This mode mimics 2 xbox 360 controllers. This mode is discouraged, cause batocera cannot differentiate from other xbox 360 pad.
Digital/Analog option	The controllers have a dpad/apad option. It has no influence on the way the controller work. It exists for compatabily issues. It is nor required nor usefull in batocera

Mapping

Since version 41, batocera doesn't use xarcade2jstick anymore to handle these controllers.

A new tool, called keyboardtopads, more generic (supporting more controllers), supporting hotkeys and configurable via emulationstation was done.

L and R are mapped to the flipper buttons too, while by convention, in batocera, L et R are the flipper keys.

Note that you can have several controllers plugged, it will automatically recognize, 4, 6, 8 players, without any issue.

Default

The mapping for the buttons is command to all the controllers.

The other buttons are set depending of their numbers to batocera control center, exit, pause hotkeys.



Customizations

When you use mode Keyboard mode, keyboardtopads splits the xarcade into 3 devices : player1, player2 and hotkeys.

A default configuration was done in batocera, but you can customize it to do an other split by going into emulationstation menu > controllers menu > keyboardtopads.



From:
<https://wiki.batocera.org/> - **Batocera.linux** - Wiki

Permanent link:
<https://wiki.batocera.org/x-arcade>

Last update: **2026/10/10 13:50**

