

X-Arcade is a serie of controllers from XGaming Corp.

It includes the following controllers :

	Name	Flipper buttons	Trackball	Spinners	Plunger	Comment
	X-Arcade Tankstick	Yes	Manual	N/A	N/A	Out of the box configuration with batocera 44. Trackball not yet configured automatically.
	X-Arcade Tankstick MAX	Yes	Manual	Manual	N/A	Out of the box configuration with batocera 44. Trackball and spinners not yet configured automatically.
	Arcade2TV-XR	Yes	Manual	Manual	N/A	Out of the box configuration with batocera 44. Trackball not yet configured automatically.
	Arcade2TV-XR MAX	Yes	Manual	Manual	Yes	Product not yet available

Modes

Mode
Keyboard
DINPUT
XINPUT
Digital/Analog option

Mapping

Since version 41, batocera doesn't use xarcade2jstick anymore to handle these controllers. A new tool, called keyboardtopads, more generic (supporting more controllers), supporting hotkeys and configurable via emulationstation was done.

Default

Customizations

When you use mode Keyboard mode, keyboardtopads splits the xarcade into 3 devices : player1, player2 and hotkeys. A default configuration was done in batocera, but you can customize it to do an other split by going into emulationstation menu > controllers menu > keyboardtopads.

From:

<https://www.wiki.batocera.org/> - **Batocera.linux - Wiki**

Permanent link:

<https://www.wiki.batocera.org/x-arcade?rev=1791625736>

Last update: **2026/10/10 09:48**

