AYN

Board	Status
Odin 1	Not yet supported
Odin 2	Supported in 42
Odin 2 Portal	Supported in 42
Thor	Supported in 43

ODIN 1

Details on Aya Odin Base/Pro

ODIN 2 and Thor Variants

Installation

1. Boot your Thor device on Android.
2. Download sm8550.zip and extract it to an sdcard.
3. In Android insert the sdcard with the extracted files.
4. Go to Android settings, at the bottom in the **Odin2 or Thor settings → Run script as Root** and select the **backup_and_flash.sh** script on the sdcard you inserted.
5. The script will run quickly and back up the original boot loader to **/sdcard/backup/** directory.
6. Keep this as a backup in case you want to rollback.
7. Download the Batocera SM8550 image and burn it on an micro SDCard. **Warning:** make sure you have a high quality SDcard. In my testings, I failed booting a 256GB no-name card, while a 128GB PNY went flawlessly.
8. Then, if you have your Batocera micro SDCard inserted in your SM8550 device, boot it up and it starts on Batocera.
9. Enter the bootloader fastboot menu by pressing `[vol -]` and `[power]` and switch the boot mode to Linux (use volume buttons and power to navigate and select).
10. Then navigate to 'Set device model'. There you can choose your device from the list. Then navigate to 'START' and press power to boot.
11. If you want to go back to Android, remove the SDCard, enter the boot loader menu by pressing `[vol +]` and `[power]` and switch the boot selection from Linux to Android. and you'll be back to Android.

Troubleshooting

You can access some boot options by keeping pressed the **[Vol +]** and **Power** buttons. The boot loader menu is in portrait mode and looks like this:



You can switch from Android to Linux booting from this menu.

From:
https://www.wiki.batocera.org/ - **Batocera.linux - Wiki**

Permanent link:
https://www.wiki.batocera.org/hardware:ayn?rev=1772678262

Last update: **2026/03/05 02:37**